

ST10 Parts Breakdown

[Call For Pricing](#)

C12	ST-10 Wireless Remote
C13	ST-10 Connector Cable
C14	ST-10 Pump
C15-500	ST-10 Heater 500 series
C15-600	ST-10 Heater 600 series
C15-700	ST-10 Heater 700 series
C16-500	Circuit Board 500 series
C16-600	Circuit Board 600 series
C16-700	Circuit Board 700 series
C17-500	Thermostat 500 series
C17-600H	Thermostat High 600 series
C17-600L	Thermostat Low 600 series
C17-700	Thermostat 700 series
C18	Superior ST-10 Wired Remote
C19	ST-10 Jug
C20	ST-10 On/Off Switch
C21-500	Handle 500 series
C21-600	Handle 600 series
C21-700	Handle 700 series
C22	Copper tube w/fittings
C23	Plastic P/U Tube, 4mm
C24	Filter
C25	Pump inlet nipple (plastic)
C26	Thermal Breaker-Manual Reset
C27	Fuse - 2A Circuit Board/Glass
C28-500/600	Fuse-12A Main/Glass-500/600
C29-500/600	Fuse Holder-500/600 series
C30-500/600	InputJackRem5PinFemale/500-600
C30-700	InputJackRemote5PinFemale/700
C31-500	Input JackDMX 3 Pin Female/500
C31-600	OutputJackRemote5PinMale/600
C31-700	OutputJackDMX3PinFemale/700
C32	Outlet Nozzle/Brass
C33	Power Cord
C34	Rubber Foot
C35-600/700	Adaptor-600/700 series
C36-700	Breaker - 15A/120V-700 series
C37-700	Output Jack(Rem) 5pin Male-700
C38-700	Input Jack(DMX) 3pin Male-700

